

## CONNECTIONS to AC DRIVE (ALTIVAR and SCHNIEDER)

1. Connect LI4 wire (for 0V reference) to COM (upper 4 pin connector, 2nd point from left).
2. Connect LI5 wire (for 10V reference) to AI2 (lower 4 pin connector, 4th point from left).
3. Take out LI3 and LI6 wires and left them unconnected, but put isolation tape on it.

